Installation Notes – ADDENDUM

SI 28
Surface Mount Speakers

This addendum applies to wall mounting the SI 28 model ONLY

The Extron SystemIntegrator® SI 28 is a two-way surface mount speaker ideally suited for classrooms, conference rooms, and boardrooms. The SI 28 can be mounted on a surface, such as a wall or post, or mounted in a bookcase, or under a shelf, and can be used with any Extron product with power amps.

Wall mounting applications

NOTE *Before starting installation ensure the wall and wall material is capable of supporting the combined weight of the speakers and the wall mount assemblies.*

To install the wall assembly mount, follow the installation steps given in "Installing the wall mount assembly", steps 1 through 9, in your *"SI 26 and SI 28 User's Manual"*.

Mounting the SI 28 speaker on the Wall Mount Assembly

To prepare the speaker for mounting, refer to "Mounting the speaker onto the wall mount assembly", steps 1 and 2 in your *"SI 26 and SI 28 User's Manual"*, then follow steps 3a through 3c and 4 below.

3a. Carefully lift the speaker up **as close to the bottom of the wall mount assembly as possible** and hook the right outer edge of the speaker box bracket over the right inner edge of the V-lock groove (see figure 1).

NOTE *Holding the speaker so that the lowest part of the speaker is as close to the bottom of the V-lock groove as possible, makes it easier to hook the two parts together.*



Figure 1 — Hooking the speaker over the edges of the V-lock groove on the wall mount assembly

3b. Rotate the speaker until the speaker box bracket left edge hooks over the left edge of the V-lock groove (see above).

3c. When the bracket is securely over the V-lock groove, gently slide the speaker down until it locks into place.

4. Repeat steps 3a to 3c for the second SI 28 speaker.

Continue installing the speakers by following "Mounting the speaker onto the wall mount assembly", steps 5 through 9 in your *"SI 26 and SI 28 User's Manual"*

www.extron.com

Extron Electronics, USA
1230 South Lewis Street
Anaheim, CA 92805
USA
714.491.1500
Fax 714.491.1517

Extron Electronics, Europe
Beeldschermweg 6C
3821 AH Amersfoort
The Netherlands
+31.33.453.4040
Fax +31.33.453.4050

Extron Electronics, Asia
135 Joo Seng Road, #04-01
PM Industrial Building
Singapore 368363
+65.6383.4400
Fax +65.6383.4664

Extron Electronics, Japan
Kyodo Building
16 Ichibancho
Chiyoda-ku, Tokyo 102-0082 Japan
+81.3.3511.7655
Fax +81.3.3511.7656

68-1338-01
Rev. Ax1
10 06

© 2006 Extron Electronics. All rights reserved.